

# Swing-Away Wet Lens Adaptor


## Fitting Instructions

Congratulations on your purchase of the Reef Images *Swing-Away Wet Lens Adaptor*. This *Adaptor* has been manufactured from quality materials, to specifically fit your Nauticam Housing's 77mm Macro Port.

To fit the *Swing Away Wet Lens Adaptor* to your housing, simply unscrew the allen-key screw on the side of the unit (see below). This will open the gap on the side of the *Adaptor*, to allow it to slip over the front of the lens port of your housing.



Push the *Adaptor* onto the housing lens port, so it sits flush to the front of the port. Tighten the *Adaptor* allen-key screw until the screw begins getting tight, turn slightly further until the Swing Away Mount feels that is firmly attached, but not so tight that it damages the port surround! Make sure the gap in the side of the unit (see below) is getting smaller, but NEVER so tight that the two edges meet. There will always be a small air gap (3 to 5 mm).



That's it! Now you can screw your 67mm wet lens into the front section of the *Adaptor*. This section swings out of the way when you want to use the camera's normal lens, but swings down in front when you want the additional magnification of your wet lens.

If your lens feels tight screwing into the *Adaptor*, STOP and check the thread on your lens is clean? It may need a small amount of silicon grease (or vaseline) on the threads of both the *Adaptor* and the wet lens. Also check the wet lens is a compatible thread size (67mm). We carry two of our own 67mm macro wet lenses, please visit our website for more details of which lens best suits your photography:

<http://www.reefwreckandcritter.com/67mm-macro-wet-lenses.html>